GroundLock Extreme Interlocking Tile

Maintenance Guidelines





EQUIPMENT REQUIRED

- 1. Dry dust mop
- 2. Auto-scrubber, low-speed rotary or cylindrical (max 350 RPM)
- 3. Buffing pads
- 4. Microfiber wet mop (do not use oil treated mops

DAILY MAINTENANCE

Maintenance Type	Equipment Used	Cleaning Products	Cleaning Methods
Manual	Dry dust mopMicrofiber wet mop	StaticWorx ScrubWorx pH- neutral cleaner	 Sweep flooring surface Wash with mop using ScrubWorx cleaner Rinse floor with clean water



Maintenance Type	Equipment Used	Cleaning Products	Cleaning Methods
Auto-scrubber	Dry dust mopAuto-scrubber3M 5000 green scrub pad	StaticWorx ScrubWorx pH- neutral cleaner	 Sweep flooring surface Scrub using ScrubWorx cleaner Vacuum up solution

BIMONTHLY-MONTHLY MAINTENANCE

Maintenance Type	Equipment Used	Cleaning Products	Cleaning Methods
Auto-scrubber	Dry dust mopAuto-scrubber3M 5100 red scrub pad	StaticWorx ScrubWorx pH- neutral cleaner	 Sweep flooring surface Scrub using ScrubWorx cleaner
			3. Vacuum up solution4. Rinse floor with clean water

INITIAL CLEANING & DEEP CLEANING

Maintenance Type	Equipment Used	Cleaning Products	Cleaning Methods
Auto-scrubber	 Dry dust mop Auto-scrubber 3M 5000 green scrub pad (initial cleaning) 3M 5100 red scrub pad (deep cleaning) 	StaticWorx ScrubWorx pH- neutral cleaner	 Sweep flooring surface Scrub using ScrubWorx cleaner Allow solution to sit for 5-10 minutes Repeat step 2 Vacuum up solution Rinse floor with clean water

NOTES

- 1. These instructions are to be used as a guide and should be adapted to the site conditions and traffic patterns observed in the different areas where GroundLock Extreme tile has been installed.
- 2. In areas where disinfection is required, always rinse with clean water after the application of the disinfectant as per their manufacturer instructions.
- 3. Never use floor cleaners with pH higher than 11.
- 4. Walk-off mats are recommended at the entrance to every room. Clean as needed on a regular basis.
- 5. Use floor mats to prevent scratching from table and chair casters.
- 6. Rubber feet on tables and chairs will stain vinyl floorcoverings. Use non-rubber protectors to prevent stains.
- 7. Never apply any commercial or ESD floor finishes to GroundLock Extreme tile.